

## **CONGRATULATIONS!!**

You have just purchased the newest, most innovative system in concrete cylinder curing. Our Thermocure I concrete cylinder curing box takes the guess work out Of your jobsite curing procedures. The Thermocure I heats the surrounding water in the tank to a constant temperature of 73 (+/-2) degrees, meeting ASTM C 31 testing standards, creating a climate for the proper curing of concrete test cylinders.

## **OPERATING INSTRUCTIONS**

**VERY IMPORTANT!! Never Operate the thermocure curing box without sufficient water in unit!!!**

1. Remove unit from carton, making sure it is in upright position. At no time should the unit be in its side or upside down.
2. Place the thermocure box on a level surface, install steel rack horizontally in curing box.
3. **Fill with water!** Be Careful! Water and Electricity can be dangerous!!
4. Unit operates on 15 amp 110 VAC, 60Hz. Connect to properly grounded 110V power supply. If an extension cord is needed, use 14 gauge or heavier.
5. Your thermocure I concrete cylinder curing box will provide you with many years of reliable service. Should you have any questions or concerns, please contact us at 1-800-223-0186.

**Thank You!!**